
KINETIC PARAMETERS CALCULATION AND MEASUREMENTS DURING THE OPAL COMMISSIONING

Daniel F. Hergenreder

Carlos A. Lecot

Eduardo A. Villarino



F. P. Moreno 1089 R8400AMU San Carlos de Bariloche, Rio Negro, Argentina



Outline


- OPAL General Description
- Kinetic Parameters Calculation
- Prompt Neutron Decay Constant Measurement
- Results
- Conclusions



OPAL General Description

- Multi-purpose open-pool type 20 MW reactor
- Core 16 Fuel Assemblies and five Absorber Plates
- Heavy Water Reflector Tank
- Radioisotope Production: Bulk Irradiation Rigs, Pneumatic Facilities, NAA, DNAA and NTD Facilities
- Neutron Beam Facilities: Cold Neutron Source, Thermal Neutron Source, Beams and Neutron Guides












Kinetic Parameters

- Effective delayed neutron fraction (β_{eff})
- Neutron lifetime (Λ)
- Prompt neutron decay constant (α)

" α is used in the Safety Analysis Report"





β_{eff} MCNP Calculation

$$\beta_{eff} = \frac{v_d N_d}{v_t N_t} \qquad \qquad N_d = \frac{v_t F R_d}{v_d} \qquad \qquad N_t = \frac{v_t F R_t}{v_t}$$

$$\beta_{eff} = \frac{FR_d}{FR_t}$$


Two Standard MCNP runs

- Run with only prompt neutrons
- Run with total neutrons (prompt + delayed)




Λ MCNP Calculation

- Simulation of the Rossi- α experiment
- SDEF calculation in a subcritical core Configuration
- Neutron population in the core as function of time





• Exponential Fitting



Measurement of α


Ratio of the Variance to the Mean number of Counts

 \Rightarrow Feynman α Method

$$V(t) = \frac{N\sum_{i=1}^{N} C_{i}^{2} - \left(\sum_{i=1}^{N} C_{i}\right)^{2}}{N\sum_{i=1}^{N} C_{i}} = 1 + \frac{\mathcal{E}\chi}{(\beta_{eff} - \rho)^{2}} \left[1 - \frac{(1 - e^{-\alpha t})}{\alpha t}\right]$$




Variance to the Mean number of Counts




Measurement & Calculation Results

IN/AP





15 FA Core Results



- Measured Value: $\alpha = 38.1 \text{ l/s}$
- MCNP Calculated Value : $\alpha = 37.2 \text{ l/s}$



Comparison beetwen Calculation Lines

IN/AP

16 Fuel Assemblies Core

	CITVAP	MCNP
β _{eff} [pcm]	768	769.5
Λ [µs]	171	171.6
α [1/s]	44.9	44.8

Conclusions

- •Standard MCNP code was used to obtain the kinetic parameters β_{eff} and Λ .
- •Good agreement between the MCNP calculated values and the values obtained by the traditional calculation line for this parameters (CITVAP code).
- •Good agreement between the measured α value and the MCNP calculated value following the Rossi- α experiment. (Measurement done with plant instrumentation).





Gansto Australian Nuclear Science and Technology Organisation